This drawing is intended only as a guide and not as a replacement for professionally engineered project drawings. This concept system drawing does not imply compliance with local building codes. Actual installation may vary depending on installation location & perameters and it must be done in accordance to all local building codes. Verify with local building officials before commencement of system installation.

\* Navien Remote required to set Cascade Unit Count Storage Tank with External Circulator Applications

